

Create an Offline Session

Create a new session. You will be able to open and edit it later. You can share it with other users of NeMo for Windows, macOS or for iOS.

Add offline device prototypes. Make up groups of devices, and zones of channels.

Choose **pictures** for the background, and make them a little blurry.





2


Choose Presets

From the Network tab or the Selector, select devices, groups, channels or zones.

Go to the Control tab and to the Setup Picker.

Build and recall presets, from a NEXO 4-channel library or channel per channel.





Prepare Your Devices' Settings and EQ


Go to the Control tab.

Select devices, groups, channels or zones from the Selector. Patch inputs to processing channels.

Edit gain, delay, etc. on:

- One channel,
- Several channels, absolute or relative.
- Mute and solo (NXAMP only).

Add and edit up to 8 EQ bands per channel.





Set Your Network Up


to edit them simultaneously. Absolute or relative.

Update your NEXO devices and their remote control cards with the latest firmware version.

٦f

Set up secured and robust Wi-Fi access points, with a unique DHCP server.

*NXES104 only: Install AVS-Monitor on a computer with Windows (PC, or Mac with virtual machine). Open AVS-Control panel and turn on AVS-Service.




Go Online

When you go online and devices are detected, NeMo automatically associates them with offline prototypes, or suggests to:

- Send values from NeMo to connected devices.
- Take values from connected devices.
- Perform a custom matching.






Check up Your System

Go to Recap.

Choose to display mute/solo. Check every channel by soloing it.



Save a Scene

NXAMP only

Select devices or groups.

Go to the Control tab and to the Scenes popover.

Select a slot and save the scene.

Later, you will be able to recall this scene and/or paste it to other NXAMPs.





Configure alerts

Select the parameters raising simple alerts
Simple alerts are automatically recorded into a text file, and raised in the events
menu.

Protection
Ch.1 to ch.4.
Stand-By
Amp Protect


i-By	
Protect	
.oad Alert	Ch.1 to ch.4. For Load Monitoring
Load Alert	Ch.1 to ch.4. For Load Monitoring
ifier Limiting Output	Reduced output level for protect
ifier Muting Output	For protection if extremely hot.

Configure red alerts

Activate and configure red alerts

Low L High

Ampli






Set up Alerts and Record the Log

Go to the preferences.

In Configure Alerts, choose the alerts to show in the Events menu.

In Configure Red Alerts, activate and set up alerts to show as pop-up messages.

To record the log, reveal the Inspector, go online, choose a Log Record, and press [R].



From the Config mode: press and hold



	() Networ	Recap Con	H) htrol					(i) Inspector
< > All Dev Bottom Left,	İCES Mid Left, Top I	Left and 17 o	others					**
Bottom Left	R0 ⁹	B112 V		Γ.	S 10 10 10 10 10 10 10 10 10 10 10 10 10		S 💐 🔐 M46 HF	
LOAD3_23	EU 67	B112 V		Γ.	© 🚉 👘 M46 MF		M46 HF	
LOAD3_23	R 6	8112 V		Γ.	S 1000000000000000000000000000000000000		M46 HF	
LOAD3_23	RI 67	8112 V		Γ.	M46 MF		M46 HF	
E Bottom Right	R 6	B112 V		Γ.	M46 MF		M46 HF	
LOAD3_23	RG ⁹	8112 V		Γ.	• 💐 😚 M46 MF		M46 HF	
Outfill Bott LOAD3_23	•	118 ОМ 🗸		Γ.	S N28 LF MAIN		2 💐 🔐 M28 HF MA	
Control Loads_23		118 ОМ V		Γ.	S 🔌 👘 M46 MF	V	M46 HF	

Click to reveal load, IP, MAC or Dante ID

Check-out the Log

Go to the Log view.

Review the key facts and the history of the parameters of your choosing. Export the log to process it in a spreadsheet.

tab.

to stop recording. — Select what to view (VU-meters, setup,...)

Components are

disabled.


Let the Show Begin

Switch to the Live mode. Components are disabled. You can go to the Preferences to configure the Live mode. While the show is ongoing, you can go to the Recap

When the show is over, go to the Log view and press [R]

Maximum hold Short-term hold

Minimum hold



Thanks for using NeMo! Please refer to the manual for further instructions and tips on how to use NeMo: <u>https://nexo-sa.com/nemo/</u>. Your feedback and comments are most welcome: <u>technical@nexo.fr</u>.

© 2023 NEXO SA. All rights reserved. <u>www.nexo-sa.com</u>. **NEXO SA cannot be held responsible for damages caused by improper use of the devices, this software and its manual. The practices contained herein may not apply to every situation.**

Apple, Mac, iPod Touch, iPhone and iPad are trademarks of Apple Inc., registered in the U.S. and other countries.

EtherSound and EtherSound logo are trademarks or registered trademarks of Digigram S.A. Dante and Dante logo are trademarks of Audinate Pty Ltd. Wi-Fi is a registered trademark of Wi-Fi Alliance. Windows is a registered trademark of Microsoft Corporation. All other trademarks are the property of their owners.