Specifications	DTD-T-U	DTD-T-N	DTD-I-U	■ DTD-I-N	
ELECTRICAL SPECIFICATIONS					
Sampling frequency and resolution Signal delay Frequency response Total harmonic distortion Dynamic range Crossover / channel separation Indicators Display Switch and rotary knobs	20 Hz to 20 KH L 112 c	48/96 KHz, 64 bits internal processing precision Less than 1 ms (analog in to out) on flat setup, compatible with NXAMP latency 20 Hz to 20 KHz, +/-0.5 dB (mains out) 20 Hz to 2 KHz +/-0.5 dB (sub out) Less than 0.001% (mains out) less than 0.02% (sub out) 112 dB (unweighted, mains out) 107 dB (unweighted, sub out) -100 dB (1kHz) Input signal/peak (green/red), amp in signal (green), speaker protect (yellow) White backlight graphical OLED display 96 x 16 pixels 3 position switch + 2 x rotary knobs			
ANALOG INPUT CHARACTERISTICS	o podition emitan	2 x rotal y raisso			
Number of channels Connectors Sampling frequency and resolution Max. input level / Input impedance	2 x XLR-F with	2 electronically balanced analog inputs 2 x XLR-F with link on XLR-M 2 x terminal block (3-pin / 2.54 mm pitch) 96 KHz / 24 bits +22 dBU / 20 kOhms			
ANALOG OUPUT CHARACTERISTICS					
Number of channels Connectors Sampling frequency and resolution Max. output level / Ouput impedance	3 x X	3 electronically balanced analog outputs 3 x XLR-M 3 x terminal block (3-pin / 2.54 mm pitch) 48/96 KHz, 24 bits +22 dBU / 200 Ohms			
AMPLIFIER SENSING INPUTS					
Number of channels Connectors Sampling frequency and resolution Max. input level / Input impedance		4 floating electronically balanced high voltage analog inputs 2 x 4 pole SP connectors 1 x terminal block (8-pin / 5.08 mm pitch) 48/96 KHz, 24 bits +50 dBU (8000 Watts / 8 Ohms) / 364 kOhms			
AES INPUT CHARACTERISTICS Number of channels Connectors	1 x X		1 x terminal block	k (3-pin / 2.54 mm pitch)	
Sampling frequency and resolution DANTETM INPUT CHARACTERISTICS		44.1 to 96kHz / 1	6, 20 or 24 bits		
Number of channels Connector Sampling frequency and resolution USB INPUT CHARACTERISTICS		2 x Dante™ channels 1 x ruggedized RJ45 48-96 kHz / 24 bits		2 x Dante™ channels 1 x RJ45 48-96 Hz / 24 bits	
Type Connector Sampling frequency and resolution		2 channels of USB audio Female mini USB connector type B 48kHz / 16 bits			
REMOTE CONTROL	Mini USB	Mini IICD - D IAE	Min: LICD	Mini USB + RJ45	
Connector PHYSICAL SPECIFICATIONS	IAIILII NOR	Mini USB + RJ45	Mini USB	WIIII USB + KJ45	
Dimensions (W x H x D) Weight Power supply voltage Power consumption Heat dissipation (per hour) Operating temperature range Storage temperature range Included items	Owners':	480 (W) x 44 (H) x 65 (D) mm, 1U 1.3 Kg 90 V - 240 V 50/60 Hz 20 W max. 20 Kcal max. 0°C - 40°C -20°C - 60°C Owners's manual Owners's manual + terminals plugs			
ORDERING INFORMATION					
Ordering code	DTD-TU	DTD-TN	DTD-IU	DTD-IN	

NEXO S. A. Parc D'Activité du Pré de la Dame Jeanne B.P.5 60128 PLAILLY France Tel: +33 (0)3 44 99 00 70 Fax: +33 (0)3 44 99 00 30 E-mail: info@nexo.fr **NEXO LatAm** Tel: +1 305 677 9322 Fax: +1 360 234 7870

Hong Kong SAR China Tel: +852 9096 3472 Fax: +852 2104 3214

NEXO Asia GPO Box 806









DIGITAL DTD

More performance in more applications

Compatible with amplifiers from other manufacturers, the DTD Digital TD Controller for PS Series cabinets and LS Subs makes the world's favourite compact, high-output system even more accessible.

Now it's possible to choose exactly the right size and scale of amplification, making PS/LS configurations accessible in a wide range of applications from small mobile systems to more sophisticated multi-cabinet installations. With advanced speaker control processing taken from the NEXO NXAMP, the DTD Digital TD Controller also delivers dramatic improvements in sonic performance over previous analog TD Controllers.

Kev Features

- Compatible with amplifiers of every size and scale
- Can be used with amplifiers from other manufacturers
- Dramatic sonic improvements over previous analog devices
- Comprehensive analog and digital connectivity plus Dante™
- Plug-and-play operation with automatic amplifier sensing
- Touring and install versions available





DTD-T touring version



The DTD-T touring version features analog input and output connectors on the front panel, removing the need for an additional patch panel

DTD-I install version



With all connectors except mini-USB located on the back panel, the DTD-I install version is set up from a Mac/PC computer

The DTD delivers advanced speaker control processing taken from the NEXO NXAMP in a compact, rack-mounting device. Providing sophisticated control over crossover, EQ and time-alignment along with speaker protection, the DTD is very easy to use, with automatic amplifier sensing and simple Sub Gain, Main Gain and Crossover Mode control available directly from the front panel (DTD-T touring version).

Flexible inputs

The DTD combines efficient speaker processing with a flexible range of inputs including stereo balanced analog inputs, an AES input and a USB port enabling direct driverless audio playback from laptops, etc. An optional Dante™ input is also available.

Advanced signal processing

DTD uses state-of-the-art audio processing to deliver highprecision EQ and Linear Acoustic Phase algorithms, phasecompatible with all PS and LS cabinets, along with other speakers in the NEXO range.

High-end AD and DA converters and 64-bit/96kHz processing ensure an analog in-to-analog-out dynamic range greater than 112dB, with distortion kept to under 0.001%.

Touring and Install versions

Both Touring (DTD-T) and Install (DTD-I) versions are housed in a rugged, low-depth rack-mounting case and feature a universal power supply.

The touring version has analog input and output connectors (XLR and Speakons) on the front panel, removing the cost need for an additional patch panel. The front panel display shows the current PS/LS set up, and features controls for Sub/Main output gain and a switch to select Wideband, Crossover or User mode. Set up from a Mac/PC connected via USB, User Mode offers additional control over Speaker/Sub model selection, Crossover Frequency selection, Delay on Main and Sub outputs, Gain for each output, Input/Output Meters including protections, User EQ (2 x 8 bands parametric), Limiters and Settings Lock with Password.

The install version has all the connectors except mini-USB located on the back panel. There is no hardware control on the unit; all parameters are set in User Mode from a Mac/PC connected via USB, allowing settings to be locked to prevent accidental changes.

Easily accessible firmware updates

The USB port can also be used to update firmware, add new functions or download new NEXO speaker presets.