


Rigging System M210 under M210




Contents:

x1	x2	x2	x12 M10x18 (a)	x8 M10x30 (a)

(a): The type of the screws may differ from the representation.

Weight: 21 kg / 46 lb



For fixation, you have the choice between M8 and M10

WARNINGS




Ensure that the mounting location and fasteners can support at least 4 times the weight of all the installed cabinets, auxiliary equipment and cables.

Use only the provided screws (thread lock coated) and accessories.

For free-hanging installation, fixing at one point in the center is permissible.


For rigid installation with tilt angle, fixation at two outer hanging points necessary.

Implementation of the first M210

Prepare the Main plates by screwing the M10x30 screws on the holes (see picture below), do not tighten completely and leave at least 6mm. Assemble the Plates on each side of M210 using the M10x18 screws.	Place the assembly below the ceiling plate.	Tighten the screws. Secure with the 4 provided M10x30 screws.
		

Implementation of the second M210

Place M210 between the plates, using 6x M10x18 screws.



ANI-LK01 frame tilt (+/- 1°)

M210	Holes 1	Holes 2	Holes 3	Holes 4	Holes 5	Holes 6	Holes 7
Tilt	+ 8°	+ 5°	+ 2°	0°	- 3°	- 6°	- 8°

- Note 1 : Holes 1 are those toward F.O.H.
- Note 2 : All angles measurements have been done without cables weight.
- Note 3 : Angles are in relation to Horizontal position ( 0° )

- NEXO cannot accept responsibility for accidents caused by any factor other than defects in this product itself.
- Please check the web site [nexo-sa.com](http://nexo-sa.com) for the latest update.

