










Rigging System M210 under 1x B218




Contents:

<p>x1 Ceiling Plate</p> 	<p>x2 Main Plate</p> 	<p>x1 Left Plate</p> 	<p>x1 M20x20 (a)</p> 
<p>X1 H Plate</p> 		<p>x1 Right Plate</p> 	<p>x12 M10x18 (a)</p> 
			<p>x12 M10x30 (a)</p> 

(a): The type of the screws may differ from the representation.

Weight: 22 kg / 48 lb





Size




For fixation, you have the choice between M8 and M10

WARNINGS	
<p>Ensure that the mounting location and fasteners can support at least 4 times the weight of all the installed cabinets, auxiliary equipment and cables.</p> <p>Use only the provided screws (thread lock coated) and accessories.</p>	
<p>For free-hanging installation, fixing at one point in the center is permissible.</p> <p>For rigid installation with tilt angle, fixation at two outer hanging points <u>necessary</u>.</p>	




Implementation of B118 – M210 with HF block in “Wide” position

<p>Place B118 on the back. Assemble H plate by screwing M20x20 screw, do not tighten completely.</p>	<p>Prepare the Main plates by screwing the M10x30 screws on the holes (see picture below), do not tighten completely and leave at least 6mm.</p> <p>Assemble the Plates on each side of B218 using the M10x18 screws. Use M10x30 for H Plate. Tighten M20x20.</p>
	
<p>Place the assembly below the ceiling plate.</p>	<p>Tighten the screws. Secure with the 4 provided M10x30 screws.</p>
	


Implementation of M210 with HF block in “Wide” position

<p>Place M210 between the plates, using 6x M10x18 screws.</p>	
---	--

Implementation of B218 – M210 with HF block in “Narrow” position

<p>Prepare the Main plates by screwing the M10x30 screws on the holes (see picture below), do not tighten completely and leave at least 6mm.</p> <p>Assemble the Plates on each side of B218 using the M10x18 screws.</p>	<p>Place the assembly below the ceiling plate.</p>	<p>Tighten the screws. Secure with the 4 provided M10x30 screws.</p>
		

Place M210 between the plates, using 6x M10x18 screws.



ANI-LK02 frame tilt (+/-1°)

	Holes 1	Holes 2	Holes 3	Holes 4	Holes 5	Holes 6	Holes 7
Tilt	+ 8°	+ 6°	+ 3°	0	- 3°	- 6°	- 8°

- Note 1 : Holes 1 are those toward F.O.H.
- Note 2 : All angles measurements have been done without cables weight.
- Note 3 : Angles are in relation to Horizontal position ( 0° )

- NEXO cannot accept responsibility for accidents caused by any factor other than defects in this product itself.
- Please check the web site [nexo-sa.com](http://nexo-sa.com) for the latest update.